














# Механизм запуска планера


Инструкция по сборке

01

					
2x	2x	1x	1x	2x	M4x8
					
M4x16					
5x	12x	5x	3x	2x	12x



02



3x




1x



1x





6x












2x




10x



03

-  2x
-  4x
-  3x
-  2x
-  5x
-  4x
-  3x
-  6x
-  1x



04

